

PCB		Housing	Terminal
4282-1-0100-02-SP	Mate with	4281-2-02-D	4281F1618-99 / 4281F1822-99 / 4281F2428-99
4282-1-0100-04-SP		4281-2-04-D	
4282-1-0100-06-SP		4281-2-06-D	
4282-1-0100-08-SP		4281-2-08-D	
4282-1-0100-10-SP		4281-2-10-D	
4282-1-0100-12-SP		4281-2-12-D	
4282-1-0100-14-SP		4281-2-14-D	
4282-1-0100-16-SP		4281-2-16-D	
4282-1-0100-18-SP		4281-2-18-D	
4282-1-0100-20-SP		4281-2-20-D	
4282-1-0100-22-SP		4281-2-22-D	
4282-1-0100-24-SP		4281-2-24-D	
4282-1-0200-02-SP		4281-2-02-D	
4282-1-0200-04-SP		4281-2-04-D	
4282-1-0200-06-SP		4281-2-06-D	
4282-1-0200-08-SP		4281-2-08-D	
4282-1-0200-10-SP		4281-2-10-D	
4282-1-0200-12-SP		4281-2-12-D	
4282-1-0200-14-SP		4281-2-14-D	
4282-1-0200-16-SP		4281-2-16-D	
4282-1-0200-18-SP		4281-2-18-D	
4282-1-0200-20-SP		4281-2-20-D	
4282-1-0200-22-SP		4281-2-22-D	
4282-1-0200-24-SP		4281-2-24-D	

Housing	Terminal		Housing	Terminal
4282-3-02-D	4282M1618-99 / 4282M1822-99 / 4282M2428-99	Mate with	4281-2-02-D	4281F1618-99 / 4281F1822-99 / 4281F2428-99
4282-3-04-D			4281-2-04-D	
4282-3-06-D			4281-2-06-D	
4282-3-08-D			4281-2-08-D	
4282-3-10-D			4281-2-10-D	
4282-3-12-D			4281-2-12-D	
4282-3-14-D			4281-2-14-D	
4282-3-16-D			4281-2-16-D	
4282-3-18-D			4281-2-18-D	
4282-3-20-D			4281-2-20-D	
4282-3-22-D			4281-2-22-D	
4282-3-24-D			4281-2-24-D	